

Principal for transport of fresh, heated air from upper room down to the cellar.  
The whole house benefits from the dry air in this way.  
The house must be relative tight (windows closed etc.) and the air must be able to pass through the house from top to bottom.

