



Counter valve seen from the side




Válvula anti retorno visto desde el lado



Schnitt von der Rückschlagklappe



Kontraspæld set fra siden



Inner flaps can be removed - and its now easy to bend the spring with a wire cutter.

Las solapas interiores se pueden sacar y así fácilmente se puede doblar el muelle.

Innere Klappen kann herausge-zogen werden. Danach kann man die kleine Feder biegen mit einer Zange.

De indre klapper kan tages ud og man kan let bukke fjeder.

